

5. MAIN Electrical Parts List

[SM-A205FN]

Parts Code	Design LOC	Description
0401-001110	D5001	DIODE-SWITCHING
0404-001250	D5000	DIODE-SCHOTTKY
0406-001506	ZD1001,ZD1002	DIODE-TVS
0406-001561	ZD5002,ZD5011,ZD6000	DIODE-TVS
0406-001561	ZD6001,ZD6026	DIODE-TVS
0406-001592	ZD5004,ZD6021	DIODE-TVS
0406-001728	ZD5001	DIODE-TVS
0406-001781	ZD6024,ZD6025	DIODE-TVS
0406-001809	ZD6015,ZD6016	DIODE-TVS
0406-001837	D6000	DIODE-TVS
0505-003618	Q5000	FET-SILICON
0601-003768	LED5000	LED
1001-001974	U1003	IC
1001-001975	U2002,U2006,U2007	IC
1001-002078	U2003	IC
1003-002802	U2004	IC
1105-002962	UCP400UP	RAM(POP)
1107-002552	UME5000	IC-FLASH MEMORY
1201-003869	U3005	IC
1201-003984	U1002,U1005	IC
1201-004100	U1006	IC
1201-004209	PAM1000	IC
1201-004228	U6001	IC
1203-008249	U3011	IC
1203-008475	U6002	IC
1203-008603	U5007	IC
1203-008693	U2001	IC
1203-008771	U3015	IC
1203-008867	U3000,U7003	IC
1203-008872	U7002,U7004	IC
1203-008925	U3013	IC
1203-008989	U7000	IC
1203-009220	U7001	IC
1203-009211	U5002	IC
1203-009213	U5001	IC
1203-009221	U7005	IC
1205-005806	U2012	IC

5. MAIN Electrical Parts List

1205-005860	U3003	IC
1205-006088	U3004	IC
1205-006117	UCP400	IC
1209-002413	U3014	IC
1209-002450	U3012	IC
1209-002629	U3016	IC
1404-001724	TH1000,TH4000,VR5000	THERMISTOR
1405-001429	V7000	VARISTOR
2007-000141	R3005,R3012,R3014	R-CHIP
2007-003015	R6062,R6063	R-CHIP
2007-007190	R6064,R6067	R-CHIP
2007-007310	R3001,R3002	R-CHIP
2007-007741	R4012,R5025,R5027	R-CHIP
2007-007741	R6061	R-CHIP
2007-007798	R6025	R-CHIP
2007-007942	R5000	R-CHIP
2007-007946	R5004	R-CHIP
2007-008052	R5022,R5024,R7001	R-CHIP
2007-008052	R7009	R-CHIP
2007-008055	R4001,R4010,R4047	R-CHIP
2007-008419	R4041,R5023	R-CHIP
2007-008483	R5020,R5021	R-CHIP
2007-008516	R3003,R4015,R4016	R-CHIP
2007-008516	R4027,R4226,R6003	R-CHIP
2007-008516	R6023,R6024	R-CHIP
2007-008531	R5015,R6009,R7000	R-CHIP
2007-008531	R7004,R7014	R-CHIP
2007-008588	R3006,R3007,R4017	R-CHIP
2007-008588	R4018,R4022,R4023	R-CHIP
2007-008588	R4024,R4026,R4030	R-CHIP
2007-008588	R4032,R4034,R4036	R-CHIP
2007-008588	R4037,R4228,R4231	R-CHIP
2007-008588	R4334,R4335,R4336	R-CHIP
2007-008800	R6012	R-CHIP
2007-008806	R2001	R-CHIP
2007-009084	R6000	R-CHIP
2007-009111	R3004,R5029	R-CHIP
2007-009157	R1007,R4002,R4003	R-CHIP
2007-009157	R5009,R5105,R6026	R-CHIP

5. MAIN Electrical Parts List

2007-009171	R5003,R5008	R-CHIP
2007-009212	R5011,R6006	R-CHIP
2007-009352	R5019	R-CHIP
2007-009361	R1000,R1002	R-CHIP
2007-009408	R6007	R-CHIP
2007-009410	R6038,R6039	R-CHIP
2007-009766	R3000	R-CHIP
2007-009793	R6014	R-CHIP
2007-009801	R5007	R-CHIP
2007-009805	R1001,R1003,R1004	R-CHIP
2007-009920	R4004,R4005,R4007	R-CHIP
2007-009920	R4009	R-CHIP
2007-009969	R6008	R-CHIP
2007-010685	R7003	R-CHIP
2007-011043	R4200,R4201,R4202	R-CHIP
2007-011043	R4203,R4333	R-CHIP
2007-011532	R6010	R-CHIP
2007-011648	R6019	R-CHIP
2007-012068	R5002	R-CHIP
2203-000330	C3050	C-CERAMIC,CHIP
2203-000489	C5173,C5174	C-CERAMIC,CHIP
2203-001153	C3044,C3052	C-CERAMIC,CHIP
2203-001239	C3049	C-CERAMIC,CHIP
2203-005344	C5267	C-CERAMIC,CHIP
2203-005682	C5117,C5123,C5556	C-CERAMIC,CHIP
2203-005725	C7006,L1038	C-CERAMIC,CHIP
2203-005729	C6000,C6004,C6010	C-CERAMIC,CHIP
2203-005729	C6015,C6018,C6019	C-CERAMIC,CHIP
2203-005729	C7011	C-CERAMIC,CHIP
2203-005731	C1125,C2055,C6058	C-CERAMIC,CHIP
2203-005731	C6059	C-CERAMIC,CHIP
2203-005732	C5049,C6009,C6016	C-CERAMIC,CHIP
2203-005732	C6017,C6022	C-CERAMIC,CHIP
2203-005734	C3057	C-CERAMIC,CHIP
2203-005736	C1000,C1003,C1006	C-CERAMIC,CHIP
2203-005736	C1017,C1018,C1022	C-CERAMIC,CHIP
2203-005736	C1034,C1040,C1052	C-CERAMIC,CHIP
2203-005736	C1053,C1060,C1083	C-CERAMIC,CHIP
2203-005736	C1084,C1085,C1091	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C1114,C2002,C2004	C-CERAMIC,CHIP
2203-005736	C2006,C2014,C2030	C-CERAMIC,CHIP
2203-005736	C2036,C2041,C2047	C-CERAMIC,CHIP
2203-005736	C2050,C3003,C3007	C-CERAMIC,CHIP
2203-005736	C3014,C3028,C3029	C-CERAMIC,CHIP
2203-005736	C3054,C3061,L1008	C-CERAMIC,CHIP
2203-005736	L1044	C-CERAMIC,CHIP
2203-005740	C3036	C-CERAMIC,CHIP
2203-005777	C1086,C1093	C-CERAMIC,CHIP
2203-005789	C1025,C1116,C1117	C-CERAMIC,CHIP
2203-005789	C1118,C1119,C1120	C-CERAMIC,CHIP
2203-005789	C1126,C1142,L1026	C-CERAMIC,CHIP
2203-005792	C1078,C1095,C1139	C-CERAMIC,CHIP
2203-005792	C2003	C-CERAMIC,CHIP
2203-005806	C1099,C1106,C1108	C-CERAMIC,CHIP
2203-005806	C2000,C3030	C-CERAMIC,CHIP
2203-006121	C6014	C-CERAMIC,CHIP
2203-006187	C6029	C-CERAMIC,CHIP
2203-006194	C6008	C-CERAMIC,CHIP
2203-006305	L2009	C-CERAMIC,CHIP
2203-006318	C1077,L1064,L2032	C-CERAMIC,CHIP
2203-006379	C6060	C-CERAMIC,CHIP
2203-006400	C1011,C2048,C3039	C-CERAMIC,CHIP
2203-006400	C3043,C3053,C4013	C-CERAMIC,CHIP
2203-006400	C6051	C-CERAMIC,CHIP
2203-006410	C1087	C-CERAMIC,CHIP
2203-006423	C2032,C3066,C3098	C-CERAMIC,CHIP
2203-006423	C3099,C4005,C5120	C-CERAMIC,CHIP
2203-006423	C5172,C5555,C6013	C-CERAMIC,CHIP
2203-006423	C6026,C6028,C7034	C-CERAMIC,CHIP
2203-006556	C1036,C3058,C5045	C-CERAMIC,CHIP
2203-006604	C1104,C3062,C6030	C-CERAMIC,CHIP
2203-006611	C1081	C-CERAMIC,CHIP
2203-006648	C6021	C-CERAMIC,CHIP
2203-006665	L1059	C-CERAMIC,CHIP
2203-006668	C4064	C-CERAMIC,CHIP
2203-006674	C2042,C3027	C-CERAMIC,CHIP
2203-006707	C1008	C-CERAMIC,CHIP
2203-006839	C1012,C1048,C1068	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006839	C1071,C1074,C1131	C-CERAMIC,CHIP
2203-006839	C2001,C4035,C5092	C-CERAMIC,CHIP
2203-006839	C5095	C-CERAMIC,CHIP
2203-006846	C1111,C4204,C4205	C-CERAMIC,CHIP
2203-006846	C4206,C4207	C-CERAMIC,CHIP
2203-006979	C2010,C2018,C2020	C-CERAMIC,CHIP
2203-006979	C2022,C2024,C2026	C-CERAMIC,CHIP
2203-006979	C2028,C2033,C2054	C-CERAMIC,CHIP
2203-007194	C1014,C3059,C3067	C-CERAMIC,CHIP
2203-007194	C7007	C-CERAMIC,CHIP
2203-007210	C4050,C4051,C4068	C-CERAMIC,CHIP
2203-007210	C4087,C5125,C5126	C-CERAMIC,CHIP
2203-007235	C5038,C5058	C-CERAMIC,CHIP
2203-007271	C2053,C4062,C5083	C-CERAMIC,CHIP
2203-007271	C5097,C5129,C7064	C-CERAMIC,CHIP
2203-007279	C7012,C7147	C-CERAMIC,CHIP
2203-007317	C3020,C3021,C7014	C-CERAMIC,CHIP
2203-007391	C2031,C5133,C5136	C-CERAMIC,CHIP
2203-007392	C5061,C5098	C-CERAMIC,CHIP
2203-007393	C1105,C2012,C3011	C-CERAMIC,CHIP
2203-007393	C3100,C3101,C4011	C-CERAMIC,CHIP
2203-007393	C4023,C4024,C4039	C-CERAMIC,CHIP
2203-007393	C4074,C4078,C5032	C-CERAMIC,CHIP
2203-007393	C5066,C5084,C5087	C-CERAMIC,CHIP
2203-007393	C5096,C5118,C5124	C-CERAMIC,CHIP
2203-007393	C5127,C5168,C5169	C-CERAMIC,CHIP
2203-007393	C5170,C5171,C6025	C-CERAMIC,CHIP
2203-007393	C7003,C7018,C7023	C-CERAMIC,CHIP
2203-007393	C7024,C7027,C7028	C-CERAMIC,CHIP
2203-007393	C7133	C-CERAMIC,CHIP
2203-007456	C5086,C6032	C-CERAMIC,CHIP
2203-007474	C2017,C2021,C2023	C-CERAMIC,CHIP
2203-007474	C2027,C2034,C4047	C-CERAMIC,CHIP
2203-007474	C4049,C4069,C5056	C-CERAMIC,CHIP
2203-007796	C2011,C2019,C2025	C-CERAMIC,CHIP
2203-007796	C2049,C3000,C3002	C-CERAMIC,CHIP
2203-007796	C3008,C3013,C3018	C-CERAMIC,CHIP
2203-007796	C3022,C3031,C3094	C-CERAMIC,CHIP
2203-007796	C3096,C3097,C3102	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C4002,C4004,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4018	C-CERAMIC,CHIP
2203-007796	C4019,C4020,C4021	C-CERAMIC,CHIP
2203-007796	C4022,C4029,C4030	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4037	C-CERAMIC,CHIP
2203-007796	C4038,C4044,C4045	C-CERAMIC,CHIP
2203-007796	C4052,C4053,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4063,C4065	C-CERAMIC,CHIP
2203-007796	C4066,C4067,C4070	C-CERAMIC,CHIP
2203-007796	C4071,C4072,C4073	C-CERAMIC,CHIP
2203-007796	C4075,C4076,C4077	C-CERAMIC,CHIP
2203-007796	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007796	C4082,C4083,C4088	C-CERAMIC,CHIP
2203-007796	C4089,C4090,C4091	C-CERAMIC,CHIP
2203-007796	C4092,C4093,C4094	C-CERAMIC,CHIP
2203-007796	C4259,C5008,C5009	C-CERAMIC,CHIP
2203-007796	C5012,C5014,C5015	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5024	C-CERAMIC,CHIP
2203-007796	C5025,C5026,C5030	C-CERAMIC,CHIP
2203-007796	C5073,C5085,C5093	C-CERAMIC,CHIP
2203-007796	C5101,C5102,C5104	C-CERAMIC,CHIP
2203-007796	C5107,C5108,C5110	C-CERAMIC,CHIP
2203-007796	C5128,C5166,C7005	C-CERAMIC,CHIP
2203-007796	C7013,C7015,C7025	C-CERAMIC,CHIP
2203-007796	C7026,C7033,C7041	C-CERAMIC,CHIP
2203-007796	C7065,C7066,C7068	C-CERAMIC,CHIP
2203-007796	C7144,C7145	C-CERAMIC,CHIP
2203-008097	C6054	C-CERAMIC,CHIP
2203-008158	C5079	C-CERAMIC,CHIP
2203-008242	C2058,C3005,C3016	C-CERAMIC,CHIP
2203-008242	C4001,C4003,C4017	C-CERAMIC,CHIP
2203-008242	C4043,C5000,C5002	C-CERAMIC,CHIP
2203-008242	C5004,C5007,C5011	C-CERAMIC,CHIP
2203-008242	C5021,C5022,C5023	C-CERAMIC,CHIP
2203-008242	C5027,C5036,C6053	C-CERAMIC,CHIP
2203-008242	C7031,C7152	C-CERAMIC,CHIP
2203-008654	C6031	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008860	C2057,C3006,C3092	C-CERAMIC,CHIP
2203-008860	C3093,C3095,C5100	C-CERAMIC,CHIP
2203-008860	C5121,C5134,C6056	C-CERAMIC,CHIP
2203-008860	C7032,C7040,C7042	C-CERAMIC,CHIP
2203-008860	C7067,C7069,C7070	C-CERAMIC,CHIP
2203-008876	C1069,C1098,C3010	C-CERAMIC,CHIP
2203-008876	C5075,C5119,C6057	C-CERAMIC,CHIP
2203-008876	C7029,C7030,C7188	C-CERAMIC,CHIP
2203-009167	C3048,C3051	C-CERAMIC,CHIP
2203-009328	C4060,C4061,C4086	C-CERAMIC,CHIP
2203-009328	C5039,C5041,C5042	C-CERAMIC,CHIP
2203-009328	C5047,C5052,C5060	C-CERAMIC,CHIP
2203-009328	C5063,C5074	C-CERAMIC,CHIP
2203-009537	C5003	C-CERAMIC,CHIP
2203-009618	C5069,C5077,C6006	C-CERAMIC,CHIP
2203-009618	C6055,C7044	C-CERAMIC,CHIP
2203-009733	C1075,C2009,C3025	C-CERAMIC,CHIP
2203-009733	C3026,C3035,C5035	C-CERAMIC,CHIP
2203-009733	C5037,C5040,C5043	C-CERAMIC,CHIP
2203-009733	C5048,C5050,C5051	C-CERAMIC,CHIP
2203-009733	C5054,C5055,C5065	C-CERAMIC,CHIP
2203-009733	C5071,C5072,C5076	C-CERAMIC,CHIP
2203-009733	C5081,C5091,C5152	C-CERAMIC,CHIP
2203-009733	C6052,C7045,C7046	C-CERAMIC,CHIP
2203-009733	C7047,C7048,C7049	C-CERAMIC,CHIP
2203-009733	C7050,C7051,C7054	C-CERAMIC,CHIP
2203-009733	C7055,C7056,C7060	C-CERAMIC,CHIP
2203-009733	C7061,C7062,C7148	C-CERAMIC,CHIP
2203-009733	C7150,C7151	C-CERAMIC,CHIP
2203-010085	C5044	C-CERAMIC,CHIP
2703-002649	L1033,L2029	INDUCTOR-SMD
2703-002903	L3013,L6010,L6011	INDUCTOR-SMD
2703-002907	C1096,L2031	INDUCTOR-SMD
2703-002955	L2020	INDUCTOR-SMD
2703-002959	L2028,L3011	INDUCTOR-SMD
2703-002999	C1112,L1005,L3027	INDUCTOR-SMD
2703-003476	L3000	INDUCTOR-SMD
2703-003970	L3014	INDUCTOR-SMD
2703-004012	L1035,L1054,L1061	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004012	L2024	INDUCTOR-SMD
2703-004013	L1028,L3015	INDUCTOR-SMD
2703-004014	L2022,L2023,L3010	INDUCTOR-SMD
2703-004018	C1057,C1127,L1007	INDUCTOR-SMD
2703-004018	L1055,L1060	INDUCTOR-SMD
2703-004032	C1092,L1032	INDUCTOR-SMD
2703-004034	C1051,C2046,L1025	INDUCTOR-SMD
2703-004034	L1029,L3002	INDUCTOR-SMD
2703-004035	L2001,L2004,L2038	INDUCTOR-SMD
2703-004036	C1129,L1011,L3004	INDUCTOR-SMD
2703-004037	L2000,L2003,L2035	INDUCTOR-SMD
2703-004038	C1063,C3040,L1023	INDUCTOR-SMD
2703-004038	L1057,L2010	INDUCTOR-SMD
2703-004171	L1016	INDUCTOR-SMD
2703-004193	L1003	INDUCTOR-SMD
2703-004286	C1059,C3038,L1010	INDUCTOR-SMD
2703-004286	L1062	INDUCTOR-SMD
2703-004317	L1013,L3001	INDUCTOR-SMD
2703-004328	L1004,L1052,L2002	INDUCTOR-SMD
2703-004328	L2007	INDUCTOR-SMD
2703-004363	L2030	INDUCTOR-SMD
2703-004367	L3016	INDUCTOR-SMD
2703-004368	L3003	INDUCTOR-SMD
2703-004408	L1017,L1021	INDUCTOR-SMD
2703-004763	C1137,C1140,L1001	INDUCTOR-SMD
2703-004763	L1053	INDUCTOR-SMD
2703-005066	L2008	INDUCTOR-SMD
2703-005085	L1063	INDUCTOR-SMD
2703-005087	L1030,L1037	INDUCTOR-SMD
2703-005200	L6012	INDUCTOR-SMD
2703-005201	L5001,L5003,L5004	INDUCTOR-SMD
2703-005201	L5005,L5011	INDUCTOR-SMD
2703-005224	L7009	INDUCTOR-SMD
2703-005296	L1041	INDUCTOR-SMD
2703-005366	C1124	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005555	L3008,L3009	INDUCTOR-SMD
2703-005689	L5002,L5006,L5007	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-005689	L5009,L5012	INDUCTOR-SMD
2801-005389	OSC5000	CRYSTAL-UNIT
2805-001117	OSC2000	OSCILLATOR
2901-001690	C4057,C4058,C4059	FILTER-EMI SMD
2901-001690	C4084,C4085,U4009	FILTER-EMI SMD
2901-001690	U4010	FILTER-EMI SMD
2904-002198	F2002	FILTER-SAW
2904-002339	F2000	FILTER-SAW
2904-002350	F1008	FILTER-SAW
2904-002355	F3002,F3003	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2904-002397	F1006,F2001	FILTER-SAW
2910-000367	F1010	FILTER
2911-000430	U2000	FILTER
2911-000450	U1007	FILTER
3003-001237	MIC6000	MIC-CONDENSOR
3301-002078	R6011	CORE-FERRITE BEAD
3301-002122	L2005,L2006,L6008	CORE-FERRITE BEAD
3301-002122	L6018	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7002	CORE-FERRITE BEAD
3301-002223	L7004	CORE-FERRITE BEAD
3301-002235	L6001,L6003,L6004	CORE-FERRITE BEAD
3301-002235	L6005,L6006,L6007	CORE-FERRITE BEAD
3301-002235	L6009,L6013	CORE-FERRITE BEAD
3301-002237	L1000,L2027,L2037	CORE-FERRITE BEAD
3301-002238	L2013,L2017,L2019	CORE-FERRITE BEAD
3301-002238	L3012,L6000,L6002	CORE-FERRITE BEAD
3301-002239	L2011	CORE-FERRITE BEAD
3301-002242	L2036	CORE-FERRITE BEAD
3301-002312	L2014,L2016,L2018	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD
3301-002331	L5008	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3709-001932	SIM4UP	CONNECTOR-CARD EDGE
3709-001933	SIM3	CONNECTOR-CARD EDGE
3709-001934	SIM1,SIM2	CONNECTOR-CARD EDGE
3710-003193	SOC7000	CONNECTOR-SOCKET
3710-003985	SOC6000	CONNECTOR-SOCKET
3711-007107	HDC7002	CONNECTOR-HEADER

5. MAIN Electrical Parts List

3711-007295	HDC7001	CONNECTOR-HEADER
3711-008511	HDC7003	CONNECTOR-HEADER
3711-008847	BTC5000	CONNECTOR-HEADER
3711-008997	HEA5000	CONNECTOR-HEADER
3712-001621	ANT2000,ANT2001	CONNECTOR
3712-001621	ANT2002,ANT2003	CONNECTOR
3712-001621	ANT2004,ANT2008	CONNECTOR
3712-001621	ANT5000,ANT5001	CONNECTOR
3712-001621	ANT5003,ANT5004	CONNECTOR
3712-001621	ANT5006	CONNECTOR
3712-001626	ANT2006,ANT2009	CONNECTOR
3712-001633	ANT3001,ANT3004	CONNECTOR
3712-001633	ANT5002,ANT5005	CONNECTOR
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001714	ANT3000,ANT3002	CONNECTOR
4709-002196	F2004	RF-MODULE
4709-002412	F1000,F1001	RF-MODULE
GH02-18335A	SC6005SP	EMI SHEET
GH61-08634A	CON1000	C-CLIP
GH62-00042A	GA7000	GASKET
GH63-16268A	SC6000	SHIELDCAN
GH63-16890A	SC6002	SHIELDCAN
GH63-16937A	SC6003	SHIELDCAN
GH63-16938A	SC6004	SHIELDCAN
GH98-44134A	SC6005	SHIELDCAN

5. MAIN Electrical Parts List

[SM-A205F]

Parts Code	Design LOC	Description
0401-001110	D5001	DIODE-SWITCHING
0404-001250	D5000	DIODE-SCHOTTKY
0406-001506	ZD1001,ZD1002	DIODE-TVS
0406-001561	ZD5002,ZD5011,ZD6000	DIODE-TVS
0406-001561	ZD6001,ZD6026	DIODE-TVS
0406-001592	ZD5004,ZD6021	DIODE-TVS
0406-001728	ZD5001	DIODE-TVS
0406-001781	ZD6024,ZD6025	DIODE-TVS
0406-001809	ZD6015,ZD6016	DIODE-TVS
0406-001837	D6000	DIODE-TVS
0505-003618	Q5000	FET-SILICON
0601-003768	LED5000	LED
1001-001974	U1003	IC
1001-001975	U2002,U2006,U2007	IC
1001-002078	U2003	IC
1003-002802	U2004	IC
1105-002962	UCP400UP	RAM(POP)
1107-002552	UME5000	IC-FLASH MEMORY
1201-003869	U3005	IC
1201-003984	U1002,U1005	IC
1201-004100	U1006	IC
1201-004209	PAM1000	IC
1201-004228	U6001	IC
1203-008249	U3011	IC
1203-008475	U6002	IC
1203-008603	U5007	IC
1203-008693	U2001	IC
1203-008771	U3015	IC
1203-008867	U7003	IC
1203-008872	U7002,U7004	IC
1203-008925	U3013	IC
1203-008989	U7000	IC
1203-009211	U5002	IC
1203-009213	U5001	IC
1203-009220	U7001	IC
1203-009221	U7005	IC
1205-005806	U2012	IC

5. MAIN Electrical Parts List

1205-005860	U3003	IC
1205-006117	UCP400	IC
1209-002413	U3014	IC
1209-002450	U3012	IC
1209-002629	U3016	IC
1404-001724	TH1000,TH4000,VR5000	THERMISTOR
1405-001429	V7000	VARISTOR
2007-000141	R3005,R3012,R3014	R-CHIP
2007-003015	R6062,R6063	R-CHIP
2007-007190	R6064,R6067	R-CHIP
2007-007741	R4013,R5025,R5027	R-CHIP
2007-007741	R6061	R-CHIP
2007-007798	R6025	R-CHIP
2007-007942	R5000	R-CHIP
2007-007946	R5004	R-CHIP
2007-008052	R5022,R5024,R7001	R-CHIP
2007-008052	R7009	R-CHIP
2007-008055	R4001,R4010,R4047	R-CHIP
2007-008419	R4041,R5023	R-CHIP
2007-008483	R5020,R5021	R-CHIP
2007-008516	R3003,R4015,R4016	R-CHIP
2007-008516	R4027,R4226,R6003	R-CHIP
2007-008516	R6023,R6024	R-CHIP
2007-008531	R5015,R6009,R7000	R-CHIP
2007-008531	R7004,R7014	R-CHIP
2007-008588	R4017,R4018,R4022	R-CHIP
2007-008588	R4023,R4024,R4026	R-CHIP
2007-008588	R4030,R4032,R4034	R-CHIP
2007-008588	R4036,R4037,R4228	R-CHIP
2007-008588	R4231,R4334,R4335	R-CHIP
2007-008588	R4336	R-CHIP
2007-008800	R6012	R-CHIP
2007-008806	R2001	R-CHIP
2007-009084	R6000	R-CHIP
2007-009111	R3004,R5029	R-CHIP
2007-009157	R1007,R4002,R4003	R-CHIP
2007-009157	R5009,R5105,R6026	R-CHIP
2007-009171	R5003,R5008	R-CHIP
2007-009212	R5011,R6006	R-CHIP

5. MAIN Electrical Parts List

2007-009352	R5019	R-CHIP
2007-009361	R1000,R1002	R-CHIP
2007-009408	R6007	R-CHIP
2007-009410	R6038,R6039	R-CHIP
2007-009766	R3000	R-CHIP
2007-009793	R6014	R-CHIP
2007-009801	R5007	R-CHIP
2007-009805	R1001,R1003,R1004	R-CHIP
2007-009920	R4004,R4005,R4007	R-CHIP
2007-009920	R4009	R-CHIP
2007-009969	R6008	R-CHIP
2007-010685	R7003	R-CHIP
2007-011043	R4200,R4201,R4202	R-CHIP
2007-011043	R4203,R4333	R-CHIP
2007-011532	R6010	R-CHIP
2007-011648	R6019	R-CHIP
2007-012068	R5002	R-CHIP
2203-000489	C5173,C5174	C-CERAMIC,CHIP
2203-005344	C5267	C-CERAMIC,CHIP
2203-005682	C5117,C5123,C5556	C-CERAMIC,CHIP
2203-005725	C7006,L1038	C-CERAMIC,CHIP
2203-005729	C6000,C6004,C6010	C-CERAMIC,CHIP
2203-005729	C6015,C6018,C6019	C-CERAMIC,CHIP
2203-005729	C7011	C-CERAMIC,CHIP
2203-005731	C1125,C2055,C6058	C-CERAMIC,CHIP
2203-005731	C6059	C-CERAMIC,CHIP
2203-005732	C5049,C6009,C6016	C-CERAMIC,CHIP
2203-005732	C6017,C6022	C-CERAMIC,CHIP
2203-005734	C3057	C-CERAMIC,CHIP
2203-005736	C1000,C1003,C1006	C-CERAMIC,CHIP
2203-005736	C1017,C1018,C1022	C-CERAMIC,CHIP
2203-005736	C1034,C1040,C1052	C-CERAMIC,CHIP
2203-005736	C1053,C1060,C1083	C-CERAMIC,CHIP
2203-005736	C1084,C1085,C1091	C-CERAMIC,CHIP
2203-005736	C1114,C2002,C2004	C-CERAMIC,CHIP
2203-005736	C2006,C2014,C2030	C-CERAMIC,CHIP
2203-005736	C2036,C2041,C2047	C-CERAMIC,CHIP
2203-005736	C2050,C3003,C3007	C-CERAMIC,CHIP
2203-005736	C3014,C3028,C3029	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C3054,C3061,L1008	C-CERAMIC,CHIP
2203-005736	L1044	C-CERAMIC,CHIP
2203-005740	C3036	C-CERAMIC,CHIP
2203-005777	C1086,C1093	C-CERAMIC,CHIP
2203-005789	C1025,C1116,C1117	C-CERAMIC,CHIP
2203-005789	C1118,C1119,C1120	C-CERAMIC,CHIP
2203-005789	C1126,C1142,L1026	C-CERAMIC,CHIP
2203-005792	C1078,C1095,C1139	C-CERAMIC,CHIP
2203-005792	C2003	C-CERAMIC,CHIP
2203-005806	C1099,C1106,C1108	C-CERAMIC,CHIP
2203-005806	C2000	C-CERAMIC,CHIP
2203-006121	C6014	C-CERAMIC,CHIP
2203-006187	C6029	C-CERAMIC,CHIP
2203-006194	C6008	C-CERAMIC,CHIP
2203-006305	L2009	C-CERAMIC,CHIP
2203-006318	C1077,L1064,L2032	C-CERAMIC,CHIP
2203-006379	C6060	C-CERAMIC,CHIP
2203-006400	C1011,C2048,C3039	C-CERAMIC,CHIP
2203-006400	C4013,C6051	C-CERAMIC,CHIP
2203-006410	C1087	C-CERAMIC,CHIP
2203-006423	C2032,C3066,C3098	C-CERAMIC,CHIP
2203-006423	C3099,C4005,C5120	C-CERAMIC,CHIP
2203-006423	C5172,C5555,C6013	C-CERAMIC,CHIP
2203-006423	C6026,C6028,C7034	C-CERAMIC,CHIP
2203-006556	C1036,C3058,C5045	C-CERAMIC,CHIP
2203-006604	C1104,C3062,C6030	C-CERAMIC,CHIP
2203-006611	C1081	C-CERAMIC,CHIP
2203-006648	C6021	C-CERAMIC,CHIP
2203-006665	L1059	C-CERAMIC,CHIP
2203-006668	C4064	C-CERAMIC,CHIP
2203-006674	C2042,C3027	C-CERAMIC,CHIP
2203-006707	C1008	C-CERAMIC,CHIP
2203-006839	C1012,C1048,C1068	C-CERAMIC,CHIP
2203-006839	C1071,C1074,C1131	C-CERAMIC,CHIP
2203-006839	C2001,C4035,C5092	C-CERAMIC,CHIP
2203-006839	C5095	C-CERAMIC,CHIP
2203-006846	C1111,C4204,C4205	C-CERAMIC,CHIP
2203-006846	C4206,C4207	C-CERAMIC,CHIP
2203-006979	C2010,C2018,C2020	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006979	C2022,C2024,C2026	C-CERAMIC,CHIP
2203-006979	C2028,C2033,C2054	C-CERAMIC,CHIP
2203-007194	C1014,C3059,C3067	C-CERAMIC,CHIP
2203-007194	C7007	C-CERAMIC,CHIP
2203-007210	C4050,C4051,C4068	C-CERAMIC,CHIP
2203-007210	C4087,C5125,C5126	C-CERAMIC,CHIP
2203-007235	C5038,C5058	C-CERAMIC,CHIP
2203-007271	C2053,C4062,C5083	C-CERAMIC,CHIP
2203-007271	C5097,C5129,C7064	C-CERAMIC,CHIP
2203-007279	C7012,C7147	C-CERAMIC,CHIP
2203-007317	C7014	C-CERAMIC,CHIP
2203-007391	C2031,C5133,C5136	C-CERAMIC,CHIP
2203-007392	C5061,C5098	C-CERAMIC,CHIP
2203-007393	C1105,C2012,C3011	C-CERAMIC,CHIP
2203-007393	C3100,C3101,C4011	C-CERAMIC,CHIP
2203-007393	C4023,C4024,C4039	C-CERAMIC,CHIP
2203-007393	C4074,C4078,C5032	C-CERAMIC,CHIP
2203-007393	C5066,C5084,C5087	C-CERAMIC,CHIP
2203-007393	C5096,C5118,C5124	C-CERAMIC,CHIP
2203-007393	C5127,C5168,C5169	C-CERAMIC,CHIP
2203-007393	C5170,C5171,C6025	C-CERAMIC,CHIP
2203-007393	C7003,C7018,C7023	C-CERAMIC,CHIP
2203-007393	C7024,C7027,C7028	C-CERAMIC,CHIP
2203-007393	C7133	C-CERAMIC,CHIP
2203-007456	C5086,C6032	C-CERAMIC,CHIP
2203-007474	C2017,C2021,C2023	C-CERAMIC,CHIP
2203-007474	C2027,C2034,C4047	C-CERAMIC,CHIP
2203-007474	C4049,C4069,C5056	C-CERAMIC,CHIP
2203-007796	C2011,C2019,C2025	C-CERAMIC,CHIP
2203-007796	C2049,C3000,C3008	C-CERAMIC,CHIP
2203-007796	C3013,C3018,C3094	C-CERAMIC,CHIP
2203-007796	C3096,C3097,C3102	C-CERAMIC,CHIP
2203-007796	C4002,C4004,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4018	C-CERAMIC,CHIP
2203-007796	C4019,C4020,C4021	C-CERAMIC,CHIP
2203-007796	C4022,C4029,C4030	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4037	C-CERAMIC,CHIP
2203-007796	C4038,C4044,C4045	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C4052,C4053,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4063,C4065	C-CERAMIC,CHIP
2203-007796	C4066,C4067,C4070	C-CERAMIC,CHIP
2203-007796	C4071,C4072,C4073	C-CERAMIC,CHIP
2203-007796	C4075,C4076,C4077	C-CERAMIC,CHIP
2203-007796	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007796	C4082,C4083,C4088	C-CERAMIC,CHIP
2203-007796	C4089,C4090,C4091	C-CERAMIC,CHIP
2203-007796	C4092,C4093,C4094	C-CERAMIC,CHIP
2203-007796	C4259,C5008,C5009	C-CERAMIC,CHIP
2203-007796	C5012,C5014,C5015	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5024	C-CERAMIC,CHIP
2203-007796	C5025,C5026,C5030	C-CERAMIC,CHIP
2203-007796	C5073,C5085,C5093	C-CERAMIC,CHIP
2203-007796	C5101,C5102,C5104	C-CERAMIC,CHIP
2203-007796	C5107,C5108,C5110	C-CERAMIC,CHIP
2203-007796	C5128,C5166,C7005	C-CERAMIC,CHIP
2203-007796	C7013,C7015,C7025	C-CERAMIC,CHIP
2203-007796	C7026,C7033,C7041	C-CERAMIC,CHIP
2203-007796	C7065,C7066,C7068	C-CERAMIC,CHIP
2203-007796	C7144,C7145	C-CERAMIC,CHIP
2203-008097	C6054	C-CERAMIC,CHIP
2203-008158	C5079	C-CERAMIC,CHIP
2203-008242	C2058,C3005,C3016	C-CERAMIC,CHIP
2203-008242	C4001,C4003,C4017	C-CERAMIC,CHIP
2203-008242	C4043,C5000,C5002	C-CERAMIC,CHIP
2203-008242	C5004,C5007,C5011	C-CERAMIC,CHIP
2203-008242	C5021,C5022,C5023	C-CERAMIC,CHIP
2203-008242	C5027,C5036,C6053	C-CERAMIC,CHIP
2203-008242	C7031,C7152	C-CERAMIC,CHIP
2203-008654	C6031	C-CERAMIC,CHIP
2203-008860	C2057,C3092,C3093	C-CERAMIC,CHIP
2203-008860	C3095,C5100,C5121	C-CERAMIC,CHIP
2203-008860	C5134,C6056,C7032	C-CERAMIC,CHIP
2203-008860	C7040,C7042,C7067	C-CERAMIC,CHIP
2203-008860	C7069,C7070	C-CERAMIC,CHIP
2203-008876	C1069,C1098,C3010	C-CERAMIC,CHIP
2203-008876	C5075,C5119,C6057	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008876	C7029,C7030,C7188	C-CERAMIC,CHIP
2203-009328	C4060,C4061,C4086	C-CERAMIC,CHIP
2203-009328	C5039,C5041,C5042	C-CERAMIC,CHIP
2203-009328	C5047,C5052,C5060	C-CERAMIC,CHIP
2203-009328	C5063,C5074	C-CERAMIC,CHIP
2203-009537	C5003	C-CERAMIC,CHIP
2203-009618	C5069,C5077,C6006	C-CERAMIC,CHIP
2203-009618	C6055,C7044	C-CERAMIC,CHIP
2203-009733	C1075,C2009,C5035	C-CERAMIC,CHIP
2203-009733	C5037,C5040,C5043	C-CERAMIC,CHIP
2203-009733	C5048,C5050,C5051	C-CERAMIC,CHIP
2203-009733	C5054,C5055,C5065	C-CERAMIC,CHIP
2203-009733	C5071,C5072,C5076	C-CERAMIC,CHIP
2203-009733	C5081,C5091,C5152	C-CERAMIC,CHIP
2203-009733	C6052,C7045,C7046	C-CERAMIC,CHIP
2203-009733	C7047,C7048,C7049	C-CERAMIC,CHIP
2203-009733	C7050,C7051,C7054	C-CERAMIC,CHIP
2203-009733	C7055,C7056,C7060	C-CERAMIC,CHIP
2203-009733	C7061,C7062,C7148	C-CERAMIC,CHIP
2203-009733	C7150,C7151	C-CERAMIC,CHIP
2203-010085	C5044	C-CERAMIC,CHIP
2703-002649	L1033,L2029	INDUCTOR-SMD
2703-002903	L3013,L6010,L6011	INDUCTOR-SMD
2703-002907	C1096,L2031	INDUCTOR-SMD
2703-002955	L2020	INDUCTOR-SMD
2703-002959	L2028,L3011	INDUCTOR-SMD
2703-002999	C1112,L1005,L3027	INDUCTOR-SMD
2703-003476	L3000	INDUCTOR-SMD
2703-003970	L3014	INDUCTOR-SMD
2703-004012	L1035,L1054,L1061	INDUCTOR-SMD
2703-004012	L2024	INDUCTOR-SMD
2703-004013	L1028,L3015	INDUCTOR-SMD
2703-004014	L2022,L2023,L3010	INDUCTOR-SMD
2703-004018	C1057,C1127,L1007	INDUCTOR-SMD
2703-004018	L1055,L1060	INDUCTOR-SMD
2703-004032	C1092,L1032	INDUCTOR-SMD
2703-004034	C1051,C2046,L1025	INDUCTOR-SMD
2703-004034	L1029,L3002	INDUCTOR-SMD
2703-004035	L2001,L2004,L2038	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004036	C1129,L1011,L3004	INDUCTOR-SMD
2703-004037	L2000,L2003,L2035	INDUCTOR-SMD
2703-004038	C1063,C3040,L1023	INDUCTOR-SMD
2703-004038	L1057,L2010	INDUCTOR-SMD
2703-004171	L1016	INDUCTOR-SMD
2703-004193	L1003	INDUCTOR-SMD
2703-004286	C1059,C3038,L1010	INDUCTOR-SMD
2703-004286	L1062	INDUCTOR-SMD
2703-004317	L1013,L3001	INDUCTOR-SMD
2703-004328	L1004,L1052,L2002	INDUCTOR-SMD
2703-004328	L2007	INDUCTOR-SMD
2703-004363	L2030	INDUCTOR-SMD
2703-004367	L3016	INDUCTOR-SMD
2703-004368	L3003	INDUCTOR-SMD
2703-004408	L1017,L1021	INDUCTOR-SMD
2703-004763	C1137,C1140,L1001	INDUCTOR-SMD
2703-004763	L1053	INDUCTOR-SMD
2703-005066	L2008	INDUCTOR-SMD
2703-005085	L1063	INDUCTOR-SMD
2703-005087	L1030,L1037	INDUCTOR-SMD
2703-005200	L6012	INDUCTOR-SMD
2703-005201	L5001,L5003,L5004	INDUCTOR-SMD
2703-005201	L5005,L5011	INDUCTOR-SMD
2703-005224	L7009	INDUCTOR-SMD
2703-005296	L1041	INDUCTOR-SMD
2703-005366	C1124	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005689	L5002,L5006,L5007	INDUCTOR-SMD
2703-005689	L5009,L5012	INDUCTOR-SMD
2801-005389	OSC5000	CRYSTAL-UNIT
2805-001117	OSC2000	OSCILLATOR
2901-001690	C4057,C4058,C4059	FILTER-EMI SMD
2901-001690	C4084,C4085,U4009	FILTER-EMI SMD
2901-001690	U4010	FILTER-EMI SMD
2904-002198	F2002	FILTER-SAW;
2904-002339	F2000	FILTER-SAW;
2904-002350	F1008	FILTER-SAW;
2904-002355	F3002,F3003	FILTER-SAW;

5. MAIN Electrical Parts List

2904-002381	F3000	FILTER-SAW;
2904-002397	F1006,F2001	FILTER-SAW;
2910-000367	F1010	FILTER
2911-000430	U2000	FILTER
2911-000450	U1007	FILTER
3003-001237	MIC6000	MIC-CONDENSOR
3301-002078	R6011	CORE-FERRITE BEAD
3301-002122	L2005,L2006,L6008	CORE-FERRITE BEAD
3301-002122	L6018	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7002	CORE-FERRITE BEAD
3301-002223	L7004	CORE-FERRITE BEAD
3301-002235	L6001,L6003,L6004	CORE-FERRITE BEAD
3301-002235	L6005,L6006,L6007	CORE-FERRITE BEAD
3301-002235	L6009,L6013	CORE-FERRITE BEAD
3301-002237	L1000,L2027,L2037	CORE-FERRITE BEAD
3301-002238	L2013,L2017,L2019	CORE-FERRITE BEAD
3301-002238	L3012,L6000,L6002	CORE-FERRITE BEAD
3301-002239	L2011	CORE-FERRITE BEAD
3301-002242	L2036	CORE-FERRITE BEAD
3301-002312	L2014,L2016,L2018	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD
3301-002331	L5008	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3709-001932	SIM4UP	CONNECTOR-CARD EDGE
3709-001933	SIM3	CONNECTOR-CARD EDGE
3709-001934	SIM1,SIM2	CONNECTOR-CARD EDGE
3710-003193	SOC7000	CONNECTOR-SOCKET
3710-003985	SOC6000	CONNECTOR-SOCKET
3711-007107	HDC7002	CONNECTOR-HEADER
3711-007295	HDC7001	CONNECTOR-HEADER
3711-008511	HDC7003	CONNECTOR-HEADER
3711-008847	BTC5000	CONNECTOR-HEADER
3711-008997	HEA5000	CONNECTOR-HEADER
3712-001621	ANT2000,ANT2001	CONNECTOR
3712-001621	ANT2002,ANT2003	CONNECTOR
3712-001621	ANT2004,ANT2008	CONNECTOR
3712-001621	ANT5000,ANT5001	CONNECTOR
3712-001621	ANT5003,ANT5004	CONNECTOR
3712-001621	ANT5006	CONNECTOR

5. MAIN Electrical Parts List

3712-001626	ANT2006,ANT2009	CONNECTOR
3712-001633	ANT5002,ANT5005	CONNECTOR
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001714	ANT3000,ANT3002	CONNECTOR
4709-002196	F2004	RF-MODULE
4709-002412	F1000,F1001	RF-MODULE
GH02-18335A	SC6005SP	EMI SHEET
GH61-08634A	CON1000	C-CLIP
GH62-00042A	GA7000	GASKET
GH63-16268A	SC6000	SHIELDCAN
GH63-16890A	SC6002	SHIELDCAN
GH63-16937A	SC6003	SHIELDCAN
GH63-16938A	SC6004	SHIELDCAN
GH98-44134A	SC6005	SHIELDCAN

5. MAIN Electrical Parts List

[SM-A205G]

Parts Code	Design LOC	Description
0401-001110	D5001	DIODE-SWITCHING
0404-001250	D5000	DIODE-SCHOTTKY
0406-001506	ZD1001,ZD1002	DIODE-TVS
0406-001561	ZD5002,ZD5011,ZD6000	DIODE-TVS
0406-001561	ZD6001,ZD6026	DIODE-TVS
0406-001592	ZD5004,ZD6021	DIODE-TVS
0406-001728	ZD5001	DIODE-TVS
0406-001781	ZD6024,ZD6025	DIODE-TVS
0406-001809	ZD6015,ZD6016	DIODE-TVS
0406-001837	D6000	DIODE-TVS
0505-003618	Q5000	FET-SILICON
0601-003768	LED5000	LED
1001-001974	U1003	IC
1001-001975	U1009,U2002,U2006	IC
1001-001975	U2007	IC
1001-002078	U2003	IC
1003-002802	U2004	IC
1105-002962	UCP400UP	RAM(POP)
1107-002552	UME5000	IC-FLASH MEMORY
1201-003869	U3005	IC
1201-003984	U1002,U1005	IC
1201-004100	U1006	IC
1201-004209	PAM1000	IC
1201-004228	U6001	IC
1203-008249	U3011	IC
1203-008475	U6002	IC
1203-008603	U5007	IC
1203-008693	U2001	IC
1203-008771	U3015	IC
1203-008867	U7003	IC
1203-008872	U7002,U7004	IC
1203-008925	U3013	IC
1203-008989	U7000	IC
1203-009211	U5002	IC
1203-009213	U5001	IC
1203-009220	U7001	IC
1203-009221	U7005	IC

5. MAIN Electrical Parts List

1205-005806	U2012	IC
1205-005860	U3003	IC
1205-006117	UCP400	IC
1209-002413	U3014	IC
1209-002450	U3012	IC
1209-002629	U3016	IC
1404-001724	TH1000,TH4000,VR5000	THERMISTOR
1405-001429	V7000	VARISTOR
2007-000141	R3005,R3012,R3014	R-CHIP
2007-003015	R6062,R6063	R-CHIP
2007-007190	R6064,R6067	R-CHIP
2007-007741	R4013,R5025,R5027	R-CHIP
2007-007741	R6061	R-CHIP
2007-007798	R6025	R-CHIP
2007-007942	R5000	R-CHIP
2007-007946	R5004	R-CHIP
2007-008052	R5022,R5024,R7001	R-CHIP
2007-008052	R7009	R-CHIP
2007-008055	R4001,R4010,R4047	R-CHIP
2007-008419	R4041,R5023	R-CHIP
2007-008483	R5020,R5021	R-CHIP
2007-008516	R3003,R4015,R4016	R-CHIP
2007-008516	R4027,R4226,R6003	R-CHIP
2007-008516	R6023,R6024	R-CHIP
2007-008531	R5015,R6009,R7000	R-CHIP
2007-008531	R7004,R7014	R-CHIP
2007-008588	R4017,R4018,R4022	R-CHIP
2007-008588	R4023,R4024,R4026	R-CHIP
2007-008588	R4030,R4032,R4034	R-CHIP
2007-008588	R4036,R4037,R4228	R-CHIP
2007-008588	R4231,R4334,R4335	R-CHIP
2007-008588	R4336	R-CHIP
2007-008800	R6012	R-CHIP
2007-008806	R2001	R-CHIP
2007-009084	R6000	R-CHIP
2007-009111	R3004,R5029	R-CHIP
2007-009157	R1007,R4002,R4003	R-CHIP
2007-009157	R5009,R5105,R6026	R-CHIP
2007-009171	R5003,R5008	R-CHIP

5. MAIN Electrical Parts List

2007-009212	R5011,R6006	R-CHIP
2007-009352	R5019	R-CHIP
2007-009361	R1000,R1002	R-CHIP
2007-009408	R6007	R-CHIP
2007-009410	R6038,R6039	R-CHIP
2007-009766	R3000	R-CHIP
2007-009793	R6014	R-CHIP
2007-009801	R5007	R-CHIP
2007-009805	R1001,R1003,R1004	R-CHIP
2007-009920	R4004,R4005,R4007	R-CHIP
2007-009920	R4009	R-CHIP
2007-009969	R6008	R-CHIP
2007-010685	R7003	R-CHIP
2007-011043	R4200,R4201,R4202	R-CHIP
2007-011043	R4203,R4333	R-CHIP
2007-011532	R6010	R-CHIP
2007-011648	R6019	R-CHIP
2007-012068	R5002	R-CHIP
2203-000489	C5173,C5174	C-CERAMIC,CHIP
2203-005344	C5267	C-CERAMIC,CHIP
2203-005682	C5117,C5123,C5556	C-CERAMIC,CHIP
2203-005725	C1133,C7006,L1038	C-CERAMIC,CHIP
2203-005727	C1123,C1132	C-CERAMIC,CHIP
2203-005729	C6000,C6004,C6010	C-CERAMIC,CHIP
2203-005729	C6015,C6018,C6019	C-CERAMIC,CHIP
2203-005729	C7011	C-CERAMIC,CHIP
2203-005731	C1125,C2055,C6058	C-CERAMIC,CHIP
2203-005731	C6059	C-CERAMIC,CHIP
2203-005732	C5049,C6009,C6016	C-CERAMIC,CHIP
2203-005732	C6017,C6022	C-CERAMIC,CHIP
2203-005734	C3057	C-CERAMIC,CHIP
2203-005736	C1000,C1003,C1006	C-CERAMIC,CHIP
2203-005736	C1017,C1018,C1022	C-CERAMIC,CHIP
2203-005736	C1028,C1034,C1040	C-CERAMIC,CHIP
2203-005736	C1052,C1053,C1060	C-CERAMIC,CHIP
2203-005736	C1072,C1083,C1084	C-CERAMIC,CHIP
2203-005736	C1085,C1091,C1114	C-CERAMIC,CHIP
2203-005736	C1141,C2002,C2004	C-CERAMIC,CHIP
2203-005736	C2006,C2014,C2030	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C2036,C2041,C2047	C-CERAMIC,CHIP
2203-005736	C2050,C3003,C3007	C-CERAMIC,CHIP
2203-005736	C3014,C3028,C3029	C-CERAMIC,CHIP
2203-005736	C3054,C3061,L1008	C-CERAMIC,CHIP
2203-005736	L1044	C-CERAMIC,CHIP
2203-005740	C3036	C-CERAMIC,CHIP
2203-005777	C1086,C1089,C1093	C-CERAMIC,CHIP
2203-005777	C1113	C-CERAMIC,CHIP
2203-005789	C1025,C1103,C1116	C-CERAMIC,CHIP
2203-005789	C1117,C1118,C1119	C-CERAMIC,CHIP
2203-005789	C1120,C1126,C1142	C-CERAMIC,CHIP
2203-005789	L1026	C-CERAMIC,CHIP
2203-005792	C1078,C1095,C1110	C-CERAMIC,CHIP
2203-005792	C1122,C1139,C2003	C-CERAMIC,CHIP
2203-005806	C1099,C1106,C1108	C-CERAMIC,CHIP
2203-005806	C2000	C-CERAMIC,CHIP
2203-006121	C6014	C-CERAMIC,CHIP
2203-006187	C6029	C-CERAMIC,CHIP
2203-006194	C6008	C-CERAMIC,CHIP
2203-006305	C1107,L2009	C-CERAMIC,CHIP
2203-006318	C1077,C1088,L1064	C-CERAMIC,CHIP
2203-006318	L2032	C-CERAMIC,CHIP
2203-006379	C6060	C-CERAMIC,CHIP
2203-006400	C1002,C1011,C2048	C-CERAMIC,CHIP
2203-006400	C3039,C4013,C6051	C-CERAMIC,CHIP
2203-006410	C1087	C-CERAMIC,CHIP
2203-006423	C2032,C3066,C3098	C-CERAMIC,CHIP
2203-006423	C3099,C4005,C5120	C-CERAMIC,CHIP
2203-006423	C5172,C5555,C6013	C-CERAMIC,CHIP
2203-006423	C6026,C6028,C7034	C-CERAMIC,CHIP
2203-006556	C1036,C3058,C5045	C-CERAMIC,CHIP
2203-006604	C1104,C3062,C6030	C-CERAMIC,CHIP
2203-006611	C1081,C1109	C-CERAMIC,CHIP
2203-006648	C6021	C-CERAMIC,CHIP
2203-006665	L1059	C-CERAMIC,CHIP
2203-006668	C4064	C-CERAMIC,CHIP
2203-006674	C2042,C3027	C-CERAMIC,CHIP
2203-006707	C1008	C-CERAMIC,CHIP
2203-006839	C1012,C1048,C1068	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006839	C1071,C1074,C1131	C-CERAMIC,CHIP
2203-006839	C1136,C2001,C4035	C-CERAMIC,CHIP
2203-006839	C5092,C5095	C-CERAMIC,CHIP
2203-006846	C1111,C4204,C4205	C-CERAMIC,CHIP
2203-006846	C4206,C4207	C-CERAMIC,CHIP
2203-006979	C2010,C2018,C2020	C-CERAMIC,CHIP
2203-006979	C2022,C2024,C2026	C-CERAMIC,CHIP
2203-006979	C2028,C2033,C2054	C-CERAMIC,CHIP
2203-007194	C1014,C3059,C3067	C-CERAMIC,CHIP
2203-007194	C7007	C-CERAMIC,CHIP
2203-007210	C4050,C4051,C4068	C-CERAMIC,CHIP
2203-007210	C4087,C5125,C5126	C-CERAMIC,CHIP
2203-007235	C5038,C5058	C-CERAMIC,CHIP
2203-007271	C2053,C4062,C5083	C-CERAMIC,CHIP
2203-007271	C5097,C5129,C7064	C-CERAMIC,CHIP
2203-007279	C7012,C7147	C-CERAMIC,CHIP
2203-007317	C7014	C-CERAMIC,CHIP
2203-007391	C2031,C5133,C5136	C-CERAMIC,CHIP
2203-007392	C5061,C5098	C-CERAMIC,CHIP
2203-007393	C1105,C2012,C3011	C-CERAMIC,CHIP
2203-007393	C3100,C3101,C4011	C-CERAMIC,CHIP
2203-007393	C4023,C4024,C4039	C-CERAMIC,CHIP
2203-007393	C4074,C4078,C5032	C-CERAMIC,CHIP
2203-007393	C5066,C5084,C5087	C-CERAMIC,CHIP
2203-007393	C5096,C5118,C5124	C-CERAMIC,CHIP
2203-007393	C5127,C5168,C5169	C-CERAMIC,CHIP
2203-007393	C5170,C5171,C6025	C-CERAMIC,CHIP
2203-007393	C7003,C7018,C7023	C-CERAMIC,CHIP
2203-007393	C7024,C7027,C7028	C-CERAMIC,CHIP
2203-007393	C7133	C-CERAMIC,CHIP
2203-007456	C5086,C6032	C-CERAMIC,CHIP
2203-007474	C2017,C2021,C2023	C-CERAMIC,CHIP
2203-007474	C2027,C2034,C4047	C-CERAMIC,CHIP
2203-007474	C4049,C4069,C5056	C-CERAMIC,CHIP
2203-007796	C2011,C2019,C2025	C-CERAMIC,CHIP
2203-007796	C2049,C3000,C3008	C-CERAMIC,CHIP
2203-007796	C3013,C3018,C3094	C-CERAMIC,CHIP
2203-007796	C3096,C3097,C3102	C-CERAMIC,CHIP
2203-007796	C4002,C4004,C4006	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4018	C-CERAMIC,CHIP
2203-007796	C4019,C4020,C4021	C-CERAMIC,CHIP
2203-007796	C4022,C4029,C4030	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4037	C-CERAMIC,CHIP
2203-007796	C4038,C4044,C4045	C-CERAMIC,CHIP
2203-007796	C4052,C4053,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4063,C4065	C-CERAMIC,CHIP
2203-007796	C4066,C4067,C4070	C-CERAMIC,CHIP
2203-007796	C4071,C4072,C4073	C-CERAMIC,CHIP
2203-007796	C4075,C4076,C4077	C-CERAMIC,CHIP
2203-007796	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007796	C4082,C4083,C4088	C-CERAMIC,CHIP
2203-007796	C4089,C4090,C4091	C-CERAMIC,CHIP
2203-007796	C4092,C4093,C4094	C-CERAMIC,CHIP
2203-007796	C4259,C5008,C5009	C-CERAMIC,CHIP
2203-007796	C5012,C5014,C5015	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5024	C-CERAMIC,CHIP
2203-007796	C5025,C5026,C5030	C-CERAMIC,CHIP
2203-007796	C5073,C5085,C5093	C-CERAMIC,CHIP
2203-007796	C5101,C5102,C5104	C-CERAMIC,CHIP
2203-007796	C5107,C5108,C5110	C-CERAMIC,CHIP
2203-007796	C5128,C5166,C7005	C-CERAMIC,CHIP
2203-007796	C7013,C7015,C7025	C-CERAMIC,CHIP
2203-007796	C7026,C7033,C7041	C-CERAMIC,CHIP
2203-007796	C7065,C7066,C7068	C-CERAMIC,CHIP
2203-007796	C7144,C7145	C-CERAMIC,CHIP
2203-008097	C6054	C-CERAMIC,CHIP
2203-008158	C5079	C-CERAMIC,CHIP
2203-008242	C2058,C3005,C3016	C-CERAMIC,CHIP
2203-008242	C4001,C4003,C4017	C-CERAMIC,CHIP
2203-008242	C4043,C5000,C5002	C-CERAMIC,CHIP
2203-008242	C5004,C5007,C5011	C-CERAMIC,CHIP
2203-008242	C5021,C5022,C5023	C-CERAMIC,CHIP
2203-008242	C5027,C5036,C6053	C-CERAMIC,CHIP
2203-008242	C7031,C7152	C-CERAMIC,CHIP
2203-008654	C6031	C-CERAMIC,CHIP
2203-008860	C2057,C3092,C3093	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008860	C3095,C5100,C5121	C-CERAMIC,CHIP
2203-008860	C5134,C6056,C7032	C-CERAMIC,CHIP
2203-008860	C7040,C7042,C7067	C-CERAMIC,CHIP
2203-008860	C7069,C7070	C-CERAMIC,CHIP
2203-008876	C1069,C1098,C3010	C-CERAMIC,CHIP
2203-008876	C5075,C5119,C6057	C-CERAMIC,CHIP
2203-008876	C7029,C7030,C7188	C-CERAMIC,CHIP
2203-009328	C4060,C4061,C4086	C-CERAMIC,CHIP
2203-009328	C5039,C5041,C5042	C-CERAMIC,CHIP
2203-009328	C5047,C5052,C5060	C-CERAMIC,CHIP
2203-009328	C5063,C5074	C-CERAMIC,CHIP
2203-009537	C5003	C-CERAMIC,CHIP
2203-009618	C5069,C5077,C6006	C-CERAMIC,CHIP
2203-009618	C6055,C7044	C-CERAMIC,CHIP
2203-009733	C1075,C2009,C5035	C-CERAMIC,CHIP
2203-009733	C5037,C5040,C5043	C-CERAMIC,CHIP
2203-009733	C5048,C5050,C5051	C-CERAMIC,CHIP
2203-009733	C5054,C5055,C5065	C-CERAMIC,CHIP
2203-009733	C5071,C5072,C5076	C-CERAMIC,CHIP
2203-009733	C5081,C5091,C5152	C-CERAMIC,CHIP
2203-009733	C6052,C7045,C7046	C-CERAMIC,CHIP
2203-009733	C7047,C7048,C7049	C-CERAMIC,CHIP
2203-009733	C7050,C7051,C7054	C-CERAMIC,CHIP
2203-009733	C7055,C7056,C7060	C-CERAMIC,CHIP
2203-009733	C7061,C7062,C7148	C-CERAMIC,CHIP
2203-009733	C7150,C7151	C-CERAMIC,CHIP
2203-010085	C5044	C-CERAMIC,CHIP
2703-002649	L1033,L1040,L1049	INDUCTOR-SMD
2703-002649	L2029	INDUCTOR-SMD
2703-002900	C1079	INDUCTOR-SMD
2703-002903	L3013,L6010,L6011	INDUCTOR-SMD
2703-002907	C1096,L2031	INDUCTOR-SMD
2703-002955	L2020	INDUCTOR-SMD
2703-002959	L2028,L3011	INDUCTOR-SMD
2703-002999	C1112,L1005,L3027	INDUCTOR-SMD
2703-003476	L3000	INDUCTOR-SMD
2703-003970	L1046,L1051,L3014	INDUCTOR-SMD
2703-004012	L1035,L1054,L1061	INDUCTOR-SMD
2703-004012	L2024	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004013	L1028,L3015	INDUCTOR-SMD
2703-004014	L2022,L2023,L3010	INDUCTOR-SMD
2703-004018	C1057,C1073,C1115	INDUCTOR-SMD
2703-004018	C1127,L1007,L1055	INDUCTOR-SMD
2703-004018	L1060	INDUCTOR-SMD
2703-004032	C1092,L1032,L1045	INDUCTOR-SMD
2703-004034	C1051,C2046,L1025	INDUCTOR-SMD
2703-004034	L1029,L3002	INDUCTOR-SMD
2703-004035	L2001,L2004,L2038	INDUCTOR-SMD
2703-004036	C1129,L1011,L3004	INDUCTOR-SMD
2703-004037	L2000,L2003,L2035	INDUCTOR-SMD
2703-004038	C1063,C3040,L1023	INDUCTOR-SMD
2703-004038	L1042,L1057,L2010	INDUCTOR-SMD
2703-004171	L1016	INDUCTOR-SMD
2703-004193	L1003	INDUCTOR-SMD
2703-004286	C1059,C3038,L1010	INDUCTOR-SMD
2703-004286	L1062	INDUCTOR-SMD
2703-004300	L1047	INDUCTOR-SMD
2703-004301	C1058	INDUCTOR-SMD
2703-004317	L1013,L3001	INDUCTOR-SMD
2703-004328	L1004,L1031,L1052	INDUCTOR-SMD
2703-004328	L2002,L2007	INDUCTOR-SMD
2703-004363	L2030	INDUCTOR-SMD
2703-004367	C1134,L3016	INDUCTOR-SMD
2703-004368	L3003,U1008	INDUCTOR-SMD
2703-004408	L1015,L1017,L1021	INDUCTOR-SMD
2703-004408	L1056	INDUCTOR-SMD
2703-004763	C1137,C1140,L1001	INDUCTOR-SMD
2703-004763	L1002,L1053	INDUCTOR-SMD
2703-004764	L2015,L2034	INDUCTOR-SMD
2703-004862	L1034	INDUCTOR-SMD
2703-005066	L2008	INDUCTOR-SMD
2703-005085	L1063	INDUCTOR-SMD
2703-005087	L1030,L1037,L1050	INDUCTOR-SMD
2703-005200	L6012	INDUCTOR-SMD
2703-005201	L5001,L5003,L5004	INDUCTOR-SMD
2703-005201	L5005,L5011	INDUCTOR-SMD
2703-005224	L7009	INDUCTOR-SMD
2703-005296	L1041,L1065	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-005366	C1124	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005689	L5002,L5006,L5007	INDUCTOR-SMD
2703-005689	L5009,L5012	INDUCTOR-SMD
2801-005389	OSC5000	CRYSTAL-UNIT
2805-001117	OSC2000	OSCILLATOR
2901-001690	C4057,C4058,C4059	FILTER-EMI SMD
2901-001690	C4084,C4085,U4009	FILTER-EMI SMD
2901-001690	U4010	FILTER-EMI SMD
2904-002198	F2002	FILTER-SAW
2904-002210	F1005	FILTER-SAW
2904-002326	F2003	FILTER-SAW
2904-002339	F2000	FILTER-SAW
2904-002350	F1008	FILTER-SAW
2904-002355	F3002,F3003	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2904-002397	F1006,F2001	FILTER-SAW
2910-000364	F1007	FILTER
2910-000367	F1010	FILTER
2910-000402	F1009	FILTER
2911-000430	U2000	FILTER
2911-000450	U1007	FILTER
3003-001237	MIC6000	MIC-CONDENSOR
3301-002078	R6011	CORE-FERRITE BEAD
3301-002122	L2005,L2006,L6008	CORE-FERRITE BEAD
3301-002122	L6018	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7002	CORE-FERRITE BEAD
3301-002223	L7004	CORE-FERRITE BEAD
3301-002235	L6001,L6003,L6004	CORE-FERRITE BEAD
3301-002235	L6005,L6006,L6007	CORE-FERRITE BEAD
3301-002235	L6009,L6013	CORE-FERRITE BEAD
3301-002237	L1000,L2027,L2037	CORE-FERRITE BEAD
3301-002238	L2013,L2017,L2019	CORE-FERRITE BEAD
3301-002238	L3012,L6000,L6002	CORE-FERRITE BEAD
3301-002239	L2011	CORE-FERRITE BEAD
3301-002242	L2036	CORE-FERRITE BEAD
3301-002312	L2014,L2016,L2018	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002331	L5008	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3709-001932	SIM4UP	CONNECTOR-CARD EDGE
3709-001933	SIM3	CONNECTOR-CARD EDGE
3709-001934	SIM1,SIM2	CONNECTOR-CARD EDGE
3710-003193	SOC7000	CONNECTOR-SOCKET
3710-003985	SOC6000	CONNECTOR-SOCKET
3711-007107	HDC7002	CONNECTOR-HEADER
3711-007295	HDC7001	CONNECTOR-HEADER
3711-008511	HDC7003	CONNECTOR-HEADER
3711-008847	BTC5000	CONNECTOR-HEADER
3711-008997	HEA5000	CONNECTOR-HEADER
3712-001621	ANT2000,ANT2001	CONNECTOR
3712-001621	ANT2002,ANT2003	CONNECTOR
3712-001621	ANT2004,ANT2008	CONNECTOR
3712-001621	ANT5000,ANT5001	CONNECTOR
3712-001621	ANT5003,ANT5004	CONNECTOR
3712-001621	ANT5006	CONNECTOR
3712-001626	ANT2006,ANT2009	CONNECTOR
3712-001633	ANT5002,ANT5005	CONNECTOR
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001714	ANT3000,ANT3002	CONNECTOR
4709-002196	F2004	RF-MODULE
4709-002412	F1000,F1001	RF-MODULE
GH02-18335A	SC6005SP	EMI SHEET
GH61-08634A	CON1000	C-CLIP
GH62-00042A	GA7000	GASKET
GH63-16268A	SC6000	SHIELDCAN
GH63-16890A	SC6002	SHIELDCAN
GH63-16937A	SC6003	SHIELDCAN
GH63-16938A	SC6004	SHIELDCAN
GH98-44134A	SC6005	SHIELDCAN

5. MAIN Electrical Parts List

[SM-A205GN]

Parts Code	Design LOC	Description
0401-001110	D5001	DIODE-SWITCHING
0404-001250	D5000	DIODE-SCHOTTKY
0406-001506	ZD1001,ZD1002	DIODE-TVS
0406-001561	ZD5002,ZD5011,ZD6000	DIODE-TVS
0406-001561	ZD6001,ZD6026	DIODE-TVS
0406-001592	ZD5004,ZD6021	DIODE-TVS
0406-001728	ZD5001	DIODE-TVS
0406-001781	ZD6024,ZD6025	DIODE-TVS
0406-001809	ZD6015,ZD6016	DIODE-TVS
0406-001837	D6000	DIODE-TVS
0505-003618	Q5000	FET-SILICON
0601-003768	LED5000	LED
1001-001974	U1003	IC
1001-001975	U1009,U2002,U2006	IC
1001-001975	U2007	IC
1001-002078	U2003	IC
1003-002802	U2004	IC
1105-002962	UCP400UP	RAM(POP)
1107-002552	UME5000	IC
1201-003869	U3005	IC
1201-003984	U1002,U1005	IC
1201-004100	U1006	IC
1201-004209	PAM1000	IC
1201-004228	U6001	IC
1203-008249	U3011	IC
1203-008475	U6002	IC
1203-008603	U5007	IC
1203-008693	U2001	IC
1203-008771	U3015	IC
1203-008867	U3000,U7003	IC
1203-008872	U7002,U7004	IC
1203-008925	U3013	IC
1203-008989	U7000	IC
1203-009211	U5002	IC
1203-009213	U5001	IC
1203-009220	U7001	IC
1203-009221	U7005	IC

5. MAIN Electrical Parts List

1205-005806	U2012	IC
1205-005860	U3003	IC
1205-006088	U3004	IC
1205-006117	UCP400	IC
1209-002413	U3014	IC
1209-002450	U3012	IC
1209-002629	U3016	IC
1404-001724	TH1000,TH4000,VR5000	THERMISTOR
1405-001429	V7000	VARISTOR
2007-000141	R3005,R3012,R3014	R-CHIP
2007-003015	R6062,R6063	R-CHIP
2007-007190	R6064,R6067	R-CHIP
2007-007310	R3001,R3002	R-CHIP
2007-007741	R4012,R5025,R5027	R-CHIP
2007-007741	R6061	R-CHIP
2007-007798	R6025	R-CHIP
2007-007942	R5000	R-CHIP
2007-007946	R5004	R-CHIP
2007-008052	R5022,R5024,R7001	R-CHIP
2007-008052	R7009	R-CHIP
2007-008055	R4001,R4010,R4047	R-CHIP
2007-008419	R4041,R5023	R-CHIP
2007-008483	R5020,R5021	R-CHIP
2007-008516	R3003,R4015,R4016	R-CHIP
2007-008516	R4027,R4226,R6003	R-CHIP
2007-008516	R6023,R6024	R-CHIP
2007-008531	R5015,R6009,R7000	R-CHIP
2007-008531	R7004,R7014	R-CHIP
2007-008588	R3006,R3007,R4017	R-CHIP
2007-008588	R4018,R4022,R4023	R-CHIP
2007-008588	R4024,R4026,R4030	R-CHIP
2007-008588	R4032,R4034,R4036	R-CHIP
2007-008588	R4037,R4228,R4231	R-CHIP
2007-008588	R4334,R4335,R4336	R-CHIP
2007-008800	R6012	R-CHIP
2007-008806	R2001	R-CHIP
2007-009084	R6000	R-CHIP
2007-009111	R3004,R5029	R-CHIP
2007-009157	R1007,R4002,R4003	R-CHIP

5. MAIN Electrical Parts List

2007-009157	R5009,R5105,R6026	R-CHIP
2007-009171	R5003,R5008	R-CHIP
2007-009212	R5011,R6006	R-CHIP
2007-009352	R5019	R-CHIP
2007-009361	R1000,R1002	R-CHIP
2007-009408	R6007	R-CHIP
2007-009410	R6038,R6039	R-CHIP
2007-009766	R3000	R-CHIP
2007-009793	R6014	R-CHIP
2007-009801	R5007	R-CHIP
2007-009805	R1001,R1003,R1004	R-CHIP
2007-009920	R4004,R4005,R4007	R-CHIP
2007-009920	R4009	R-CHIP
2007-009969	R6008	R-CHIP
2007-010685	R7003	R-CHIP
2007-011043	R4200,R4201,R4202	R-CHIP
2007-011043	R4203,R4333	R-CHIP
2007-011532	R6010	R-CHIP
2007-011648	R6019	R-CHIP
2007-012068	R5002	R-CHIP
2203-000330	C3050	C-CERAMIC,CHIP
2203-000489	C5173,C5174	C-CERAMIC,CHIP
2203-001153	C3044,C3052	C-CERAMIC,CHIP
2203-001239	C3049	C-CERAMIC,CHIP
2203-005344	C5267	C-CERAMIC,CHIP
2203-005682	C5117,C5123,C5556	C-CERAMIC,CHIP
2203-005725	C1133,C7006,L1038	C-CERAMIC,CHIP
2203-005727	C1123,C1132	C-CERAMIC,CHIP
2203-005729	C6000,C6004,C6010	C-CERAMIC,CHIP
2203-005729	C6015,C6018,C6019	C-CERAMIC,CHIP
2203-005729	C7011	C-CERAMIC,CHIP
2203-005731	C1125,C2055,C6058	C-CERAMIC,CHIP
2203-005731	C6059	C-CERAMIC,CHIP
2203-005732	C5049,C6009,C6016	C-CERAMIC,CHIP
2203-005732	C6017,C6022	C-CERAMIC,CHIP
2203-005734	C3057	C-CERAMIC,CHIP
2203-005736	C1000,C1003,C1006	C-CERAMIC,CHIP
2203-005736	C1017,C1018,C1022	C-CERAMIC,CHIP
2203-005736	C1028,C1034,C1040	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C1052,C1053,C1060	C-CERAMIC,CHIP
2203-005736	C1072,C1083,C1084	C-CERAMIC,CHIP
2203-005736	C1085,C1091,C1114	C-CERAMIC,CHIP
2203-005736	C1141,C2002,C2004	C-CERAMIC,CHIP
2203-005736	C2006,C2014,C2030	C-CERAMIC,CHIP
2203-005736	C2036,C2041,C2047	C-CERAMIC,CHIP
2203-005736	C2050,C3003,C3007	C-CERAMIC,CHIP
2203-005736	C3014,C3028,C3029	C-CERAMIC,CHIP
2203-005736	C3054,C3061,L1008	C-CERAMIC,CHIP
2203-005736	L1044	C-CERAMIC,CHIP
2203-005740	C3036	C-CERAMIC,CHIP
2203-005777	C1086,C1089,C1093	C-CERAMIC,CHIP
2203-005777	C1113	C-CERAMIC,CHIP
2203-005789	C1025,C1103,C1116	C-CERAMIC,CHIP
2203-005789	C1117,C1118,C1119	C-CERAMIC,CHIP
2203-005789	C1120,C1126,C1142	C-CERAMIC,CHIP
2203-005789	L1026	C-CERAMIC,CHIP
2203-005792	C1078,C1095,C1110	C-CERAMIC,CHIP
2203-005792	C1122,C1139,C2003	C-CERAMIC,CHIP
2203-005806	C1099,C1106,C1108	C-CERAMIC,CHIP
2203-005806	C2000,C3030	C-CERAMIC,CHIP
2203-006121	C6014	C-CERAMIC,CHIP
2203-006187	C6029	C-CERAMIC,CHIP
2203-006194	C6008	C-CERAMIC,CHIP
2203-006305	C1107,L2009	C-CERAMIC,CHIP
2203-006318	C1077,C1088,L1064	C-CERAMIC,CHIP
2203-006318	L2032	C-CERAMIC,CHIP
2203-006379	C6060	C-CERAMIC,CHIP
2203-006400	C1002,C1011,C2048	C-CERAMIC,CHIP
2203-006400	C3039,C3043,C3053	C-CERAMIC,CHIP
2203-006400	C4013,C6051	C-CERAMIC,CHIP
2203-006410	C1087	C-CERAMIC,CHIP
2203-006423	C2032,C3066,C3098	C-CERAMIC,CHIP
2203-006423	C3099,C4005,C5120	C-CERAMIC,CHIP
2203-006423	C5172,C5555,C6013	C-CERAMIC,CHIP
2203-006423	C6026,C6028,C7034	C-CERAMIC,CHIP
2203-006556	C1036,C3058,C5045	C-CERAMIC,CHIP
2203-006604	C1104,C3062,C6030	C-CERAMIC,CHIP
2203-006611	C1081,C1109	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006648	C6021	C-CERAMIC,CHIP
2203-006665	L1059	C-CERAMIC,CHIP
2203-006668	C4064	C-CERAMIC,CHIP
2203-006674	C2042,C3027	C-CERAMIC,CHIP
2203-006707	C1008	C-CERAMIC,CHIP
2203-006839	C1012,C1048,C1068	C-CERAMIC,CHIP
2203-006839	C1071,C1074,C1131	C-CERAMIC,CHIP
2203-006839	C1136,C2001,C4035	C-CERAMIC,CHIP
2203-006839	C5092,C5095	C-CERAMIC,CHIP
2203-006846	C1111,C4204,C4205	C-CERAMIC,CHIP
2203-006846	C4206,C4207	C-CERAMIC,CHIP
2203-006979	C2010,C2018,C2020	C-CERAMIC,CHIP
2203-006979	C2022,C2024,C2026	C-CERAMIC,CHIP
2203-006979	C2028,C2033,C2054	C-CERAMIC,CHIP
2203-007194	C1014,C3059,C3067	C-CERAMIC,CHIP
2203-007194	C7007	C-CERAMIC,CHIP
2203-007210	C4050,C4051,C4068	C-CERAMIC,CHIP
2203-007210	C4087,C5125,C5126	C-CERAMIC,CHIP
2203-007235	C5038,C5058	C-CERAMIC,CHIP
2203-007271	C2053,C4062,C5083	C-CERAMIC,CHIP
2203-007271	C5097,C5129,C7064	C-CERAMIC,CHIP
2203-007279	C7012,C7147	C-CERAMIC,CHIP
2203-007317	C3020,C3021,C7014	C-CERAMIC,CHIP
2203-007391	C2031,C5133,C5136	C-CERAMIC,CHIP
2203-007392	C5061,C5098	C-CERAMIC,CHIP
2203-007393	C1105,C2012,C3011	C-CERAMIC,CHIP
2203-007393	C3100,C3101,C4011	C-CERAMIC,CHIP
2203-007393	C4023,C4024,C4039	C-CERAMIC,CHIP
2203-007393	C4074,C4078,C5032	C-CERAMIC,CHIP
2203-007393	C5066,C5084,C5087	C-CERAMIC,CHIP
2203-007393	C5096,C5118,C5124	C-CERAMIC,CHIP
2203-007393	C5127,C5168,C5169	C-CERAMIC,CHIP
2203-007393	C5170,C5171,C6025	C-CERAMIC,CHIP
2203-007393	C7003,C7018,C7023	C-CERAMIC,CHIP
2203-007393	C7024,C7027,C7028	C-CERAMIC,CHIP
2203-007393	C7133	C-CERAMIC,CHIP
2203-007456	C5086,C6032	C-CERAMIC,CHIP
2203-007474	C2017,C2021,C2023	C-CERAMIC,CHIP
2203-007474	C2027,C2034,C4047	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007474	C4049,C4069,C5056	C-CERAMIC,CHIP
2203-007796	C2011,C2019,C2025	C-CERAMIC,CHIP
2203-007796	C2049,C3000,C3002	C-CERAMIC,CHIP
2203-007796	C3008,C3013,C3018	C-CERAMIC,CHIP
2203-007796	C3022,C3031,C3094	C-CERAMIC,CHIP
2203-007796	C3096,C3097,C3102	C-CERAMIC,CHIP
2203-007796	C4002,C4004,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4018	C-CERAMIC,CHIP
2203-007796	C4019,C4020,C4021	C-CERAMIC,CHIP
2203-007796	C4022,C4029,C4030	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4037	C-CERAMIC,CHIP
2203-007796	C4038,C4044,C4045	C-CERAMIC,CHIP
2203-007796	C4052,C4053,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4063,C4065	C-CERAMIC,CHIP
2203-007796	C4066,C4067,C4070	C-CERAMIC,CHIP
2203-007796	C4071,C4072,C4073	C-CERAMIC,CHIP
2203-007796	C4075,C4076,C4077	C-CERAMIC,CHIP
2203-007796	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007796	C4082,C4083,C4088	C-CERAMIC,CHIP
2203-007796	C4089,C4090,C4091	C-CERAMIC,CHIP
2203-007796	C4092,C4093,C4094	C-CERAMIC,CHIP
2203-007796	C4259,C5008,C5009	C-CERAMIC,CHIP
2203-007796	C5012,C5014,C5015	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5024	C-CERAMIC,CHIP
2203-007796	C5025,C5026,C5030	C-CERAMIC,CHIP
2203-007796	C5073,C5085,C5093	C-CERAMIC,CHIP
2203-007796	C5101,C5102,C5104	C-CERAMIC,CHIP
2203-007796	C5107,C5108,C5110	C-CERAMIC,CHIP
2203-007796	C5128,C5166,C7005	C-CERAMIC,CHIP
2203-007796	C7013,C7015,C7025	C-CERAMIC,CHIP
2203-007796	C7026,C7033,C7041	C-CERAMIC,CHIP
2203-007796	C7065,C7066,C7068	C-CERAMIC,CHIP
2203-007796	C7144,C7145	C-CERAMIC,CHIP
2203-008097	C6054	C-CERAMIC,CHIP
2203-008158	C5079	C-CERAMIC,CHIP
2203-008242	C2058,C3005,C3016	C-CERAMIC,CHIP
2203-008242	C4001,C4003,C4017	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008242	C4043,C5000,C5002	C-CERAMIC,CHIP
2203-008242	C5004,C5007,C5011	C-CERAMIC,CHIP
2203-008242	C5021,C5022,C5023	C-CERAMIC,CHIP
2203-008242	C5027,C5036,C6053	C-CERAMIC,CHIP
2203-008242	C7031,C7152	C-CERAMIC,CHIP
2203-008654	C6031	C-CERAMIC,CHIP
2203-008860	C2057,C3006,C3092	C-CERAMIC,CHIP
2203-008860	C3093,C3095,C5100	C-CERAMIC,CHIP
2203-008860	C5121,C5134,C6056	C-CERAMIC,CHIP
2203-008860	C7032,C7040,C7042	C-CERAMIC,CHIP
2203-008860	C7067,C7069,C7070	C-CERAMIC,CHIP
2203-008876	C1069,C1098,C3010	C-CERAMIC,CHIP
2203-008876	C5075,C5119,C6057	C-CERAMIC,CHIP
2203-008876	C7029,C7030,C7188	C-CERAMIC,CHIP
2203-009167	C3048,C3051	C-CERAMIC,CHIP
2203-009328	C4060,C4061,C4086	C-CERAMIC,CHIP
2203-009328	C5039,C5041,C5042	C-CERAMIC,CHIP
2203-009328	C5047,C5052,C5060	C-CERAMIC,CHIP
2203-009328	C5063,C5074	C-CERAMIC,CHIP
2203-009537	C5003	C-CERAMIC,CHIP
2203-009618	C5069,C5077,C6006	C-CERAMIC,CHIP
2203-009618	C6055,C7044	C-CERAMIC,CHIP
2203-009733	C1075,C2009,C3025	C-CERAMIC,CHIP
2203-009733	C3026,C3035,C5035	C-CERAMIC,CHIP
2203-009733	C5037,C5040,C5043	C-CERAMIC,CHIP
2203-009733	C5048,C5050,C5051	C-CERAMIC,CHIP
2203-009733	C5054,C5055,C5065	C-CERAMIC,CHIP
2203-009733	C5071,C5072,C5076	C-CERAMIC,CHIP
2203-009733	C5081,C5091,C5152	C-CERAMIC,CHIP
2203-009733	C6052,C7045,C7046	C-CERAMIC,CHIP
2203-009733	C7047,C7048,C7049	C-CERAMIC,CHIP
2203-009733	C7050,C7051,C7054	C-CERAMIC,CHIP
2203-009733	C7055,C7056,C7060	C-CERAMIC,CHIP
2203-009733	C7061,C7062,C7148	C-CERAMIC,CHIP
2203-009733	C7150,C7151	C-CERAMIC,CHIP
2203-010085	C5044	C-CERAMIC,CHIP
2703-002649	L1033,L1040,L1049	INDUCTOR-SMD
2703-002649	L2029	INDUCTOR-SMD
2703-002900	C1079	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-002903	L3013,L6010,L6011	INDUCTOR-SMD
2703-002907	C1096,L2031	INDUCTOR-SMD
2703-002955	L2020	INDUCTOR-SMD
2703-002959	L2028,L3011	INDUCTOR-SMD
2703-002999	C1112,L1005,L3027	INDUCTOR-SMD
2703-003476	L3000	INDUCTOR-SMD
2703-003970	L1046,L1051,L3014	INDUCTOR-SMD
2703-004012	L1035,L1054,L1061	INDUCTOR-SMD
2703-004012	L2024	INDUCTOR-SMD
2703-004013	L1028,L3015	INDUCTOR-SMD
2703-004014	L2022,L2023,L3010	INDUCTOR-SMD
2703-004018	C1057,C1073,C1115	INDUCTOR-SMD
2703-004018	C1127,L1007,L1055	INDUCTOR-SMD
2703-004018	L1060	INDUCTOR-SMD
2703-004032	C1092,L1032,L1045	INDUCTOR-SMD
2703-004034	C1051,C2046,L1025	INDUCTOR-SMD
2703-004034	L1029,L3002	INDUCTOR-SMD
2703-004035	L2001,L2004,L2038	INDUCTOR-SMD
2703-004036	C1129,L1011,L3004	INDUCTOR-SMD
2703-004037	L2000,L2003,L2035	INDUCTOR-SMD
2703-004038	C1063,C3040,L1023	INDUCTOR-SMD
2703-004038	L1042,L1057,L2010	INDUCTOR-SMD
2703-004171	L1016	INDUCTOR-SMD
2703-004193	L1003	INDUCTOR-SMD
2703-004286	C1059,C3038,L1010	INDUCTOR-SMD
2703-004286	L1062	INDUCTOR-SMD
2703-004300	L1047	INDUCTOR-SMD
2703-004301	C1058	INDUCTOR-SMD
2703-004317	L1013,L3001	INDUCTOR-SMD
2703-004328	L1004,L1031,L1052	INDUCTOR-SMD
2703-004328	L2002,L2007	INDUCTOR-SMD
2703-004363	L2030	INDUCTOR-SMD
2703-004367	C1134,L3016	INDUCTOR-SMD
2703-004368	L3003,U1008	INDUCTOR-SMD
2703-004408	L1015,L1017,L1021	INDUCTOR-SMD
2703-004408	L1056	INDUCTOR-SMD
2703-004763	C1137,C1140,L1001	INDUCTOR-SMD
2703-004763	L1002,L1053	INDUCTOR-SMD
2703-004764	L2015,L2034	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004862	L1034	INDUCTOR-SMD
2703-005066	L2008	INDUCTOR-SMD
2703-005085	L1063	INDUCTOR-SMD
2703-005087	L1030,L1037,L1050	INDUCTOR-SMD
2703-005200	L6012	INDUCTOR-SMD
2703-005201	L5001,L5003,L5004	INDUCTOR-SMD
2703-005201	L5005,L5011	INDUCTOR-SMD
2703-005224	L7009	INDUCTOR-SMD
2703-005296	L1041,L1065	INDUCTOR-SMD
2703-005366	C1124	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005555	L3008,L3009	INDUCTOR-SMD
2703-005689	L5002,L5006,L5007	INDUCTOR-SMD
2703-005689	L5009,L5012	INDUCTOR-SMD
2801-005389	OSC5000	CRYSTAL-UNIT
2805-001117	OSC2000	OSCILLATOR
2901-001690	C4057,C4058,C4059	FILTER-EMI SMD
2901-001690	C4084,C4085,U4009	FILTER-EMI SMD
2901-001690	U4010	FILTER-EMI SMD
2904-002198	F2002	FILTER-SAW
2904-002210	F1005	FILTER-SAW
2904-002326	F2003	FILTER-SAW
2904-002339	F2000	FILTER-SAW
2904-002350	F1008	FILTER-SAW
2904-002355	F3002,F3003	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2904-002397	F1006,F2001	FILTER-SAW
2910-000364	F1007	FILTER
2910-000367	F1010	FILTER
2910-000402	F1009	FILTER
2911-000430	U2000	FILTER
2911-000450	U1007	FILTER
3003-001237	MIC6000	MIC-CONDENSOR
3301-002078	R6011	CORE-FERRITE BEAD
3301-002122	L2005,L2006,L6008	CORE-FERRITE BEAD
3301-002122	L6018	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7002	CORE-FERRITE BEAD
3301-002223	L7004	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002235	L6001,L6003,L6004	CORE-FERRITE BEAD
3301-002235	L6005,L6006,L6007	CORE-FERRITE BEAD
3301-002235	L6009,L6013	CORE-FERRITE BEAD
3301-002237	L1000,L2027,L2037	CORE-FERRITE BEAD
3301-002238	L2013,L2017,L2019	CORE-FERRITE BEAD
3301-002238	L3012,L6000,L6002	CORE-FERRITE BEAD
3301-002239	L2011	CORE-FERRITE BEAD
3301-002242	L2036	CORE-FERRITE BEAD
3301-002312	L2014,L2016,L2018	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD
3301-002331	L5008	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3709-001932	SIM4UP	CONNECTOR-CARD EDGE
3709-001933	SIM3	CONNECTOR-CARD EDGE
3709-001934	SIM1,SIM2	CONNECTOR-CARD EDGE
3710-003193	SOC7000	CONNECTOR-SOCKET
3710-003985	SOC6000	CONNECTOR-SOCKET
3711-007107	HDC7002	CONNECTOR-HEADER
3711-007295	HDC7001	CONNECTOR-HEADER
3711-008511	HDC7003	CONNECTOR-HEADER
3711-008847	BTC5000	CONNECTOR-HEADER
3711-008997	HEA5000	CONNECTOR-HEADER
3712-001621	ANT2000,ANT2001	CONNECTOR
3712-001621	ANT2002,ANT2003	CONNECTOR
3712-001621	ANT2004,ANT2008	CONNECTOR
3712-001621	ANT5000,ANT5001	CONNECTOR
3712-001621	ANT5003,ANT5004	CONNECTOR
3712-001621	ANT5006	CONNECTOR
3712-001626	ANT2006,ANT2009	CONNECTOR
3712-001633	ANT3001,ANT3004	CONNECTOR
3712-001633	ANT5002,ANT5005	CONNECTOR
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001714	ANT3000,ANT3002	CONNECTOR
4709-002196	F2004	RF-MODULE
4709-002412	F1000,F1001	RF-MODULE
GH02-18335A	SC6005SP	EMI SHEET
GH61-08634A	CON1000	C-CLIP
GH62-00042A	GA7000	GASKET
GH63-16268A	SC6000	SHIELD CAN

5. MAIN Electrical Parts List

GH63-16890A	SC6002	SHIELDKAN
GH63-16937A	SC6003	SHIELDKAN
GH63-16938A	SC6004	SHIELDKAN
GH98-44134A	SC6005	SHIELDKAN

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.



Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.