

7-1. Components on the Rear Case







7-2. Pre-requisite





7-3. Parts which must be changed after repair

BOM description & part code	KIT CODE	Image	Remarks
A/S-SVC TAPE BG WP OUTER (Common) [GH81-15386A]	A/S REWORK KIT- SM-G965F (N.A)		Replace for
A/S-SVC TAPE BG INNER (N.A) [GH81-15388A]	[GH82-15965A] Include Waterproof Tape KIT Package - BG WP Outer Tape - BG INNER Tape - FP Module Tape - Camera Sealing Tape 1EA - MIC Sealing		Back Glass repair
TAPE FP MODULE [GH02-15926A]	Tape 2EA		Replace for Back Glass Or Finger print sensor repair



7-4. Disassembly

1

Put the device in the chamber as following below heating condition

- SOC 68%↓: 70 °C/10~20 minute
- SOC 68%↑: 70 ℃/10~20 minute
- * Please confirm the heating condition released lastly, and follow it.





Put the device in to HOT PLATE.(70°C/10mins)

2

Detach the Back Glass. And Finger sensor

- 1) Detach the left side of Back glass
- 2) Detach the Finger sensor connector





X Caution
Be care of scratch

3

Unscrew 16 Point and disassemble SIM Tray

from device



Caution
 Be care of Rear damage

4

Disassemble Upper Rear. (Use disassemble hole left/right side of Rear to detach it)



Rear Top disassemble hole.

X Caution

- 1) Be care of scratch
- 2) Be care of Rear and connector damage

Finally Disassemble Rear of bottom side.
(Use disassemble hole right side of Rear to detach it)



6 Unscrew PBA 1points.



- **X** Caution
- 1) Be care of scratch
- 2) Be care of Rear and connector damage
- 3) Be careful not to damage the PBA

☆ Caution

Be careful not to damage the PBA

2 coaxial cable, Battery connect and the other connectors. (8 Point)




8 Detach SUB PBA connector



- * Caution
- 1) Be care of scratch
- 2) Be care of connector/cable damage

- * Caution
- 1) Be care of FPCB damage
- 2) Be care of SUB PBA connector




: COMTECH Semples Computer Schnidgy

tamiraat.com

13 Detach SUB PBA (2/4)



14 Detach SUB PBA (3/4)



Disassemble Left side

Caution
 Be care of SUB PBA damage

Caution
Be care of SUB PBA damage

15 Detach SUB PBA (2/4)



Disassemble Up side

Caution
 Be care of SUB PBA damage





7-5. Assembly

1 Attach SUB PBA and Ear jack on Front.

2

Screw 5point in SUB PBA.





Caution

Be care of coaxial cable damage


X Caution

Be care of chip damage nearby screw point.

Attach components on Front. (TOP SPK, Sensor FPCB, Motor)

TOP SPK

Proximity Sensor



4

Attach PBA assy In Front Assy. (PBA+ Front)



- Caution
- 1) Be care of FPCB damage and tilt
- 2) Be care of press power/time

- Caution
- 1) Be care of Push SUB PBA connector.
- 2) Be care of components FPCB.

لینک کانال: schimatics@



•

5 Attach Front CAM and Iris CAM on PBA.





Attach 2 coaxial cable, Battery connect and the other connectors. (8 Point)




Caution
Be care of press power/time

Caution
 Be care of FPCB and Y-OCTA damage

7 Assemble the Bottom REAR in sequence.



Assemble the TOP+MID REAR Assy in sequence.



Caution
Be care of scratch and REAR damage

Caution

8

Be care of scratch and REAR damage

:JUS SECONTECH

@schimatites


9

Unscrew 16 Point and disassemble SIM Tray from device

* Screw Torque: 1.3Kgf



Attach the finger sensor on the REAR and Assemble the finger sensor on the PBA



Caution

Be care of scratch and REAR damage

Caution


Be care of scratch and tilt.

11

Attach the back glass inner tape on the backglass

12

Attach the finger tape on the back glass.





X Caution

Be care of scratch and tilt.

※ Caution

Be care of scratch and tilt.



